


**CS-435**

spring semester 2020

## Network Technology & Programming Laboratory

University of Crete  
Computer Science Department

**Stefanos Papadakis**



# CS-435

## Lecture #10 preview

- Wireless Networking
- Radio Communications Explored



# two endpoints



# SINR

- What is interference?

$$I_{Rx}$$

- What is noise?

$$N = k_B T \Delta f$$

- noise floor

$$F = \frac{SNR_{in}}{SNR_{out}}$$

- noise factor / noise figure

$$NF = 10 \log \left( \frac{SNR_{in}}{SNR_{out}} \right)$$

- SNR / SINR / SIR

$$SNR = \frac{P_{Rx}}{N}$$

$$SINR = \frac{P_{Rx}}{I_{Rx} + N}$$



# Sensitivity

- SINR is not the only criterion for reception!
- The Received Signal power must be over a threshold
- Vendors usually provide only RSS thresholds, not SINR

| RX SPECIFICATIONS |          |             |           |
|-------------------|----------|-------------|-----------|
|                   | DataRate | Sensitivity | Tolerance |
| 802.11b           | 1Mbps    | -97 dBm     | +/-1dB    |
|                   | 2Mbps    | -96 dBm     | +/-1dB    |
|                   | 5.5Mbps  | -95 dBm     | +/-1dB    |
|                   | 11Mbps   | -92 dBm     | +/-1dB    |
| 802.11g OFDM      | 6Mbps    | -94 dBm     | +/-1dB    |
|                   | 9Mbps    | -93 dBm     | +/-1dB    |
|                   | 12Mbps   | -91 dBm     | +/-1dB    |
|                   | 18Mbps   | -90 dBm     | +/-1dB    |
|                   | 24Mbps   | -86 dBm     | +/-1dB    |
|                   | 36Mbps   | -83 dBm     | +/-1dB    |
|                   | 48Mbps   | -77 dBm     | +/-1dB    |
|                   | 54Mbps   | -74 dBm     | +/-1dB    |
| 802.11n HT        | 24Mbps   | -94 dBm     | +/-1dB    |
|                   | 48Mbps   | -91 dBm     | +/-1dB    |
|                   | 36Mbps   | -83 dBm     | +/-1dB    |
|                   | 54Mbps   | -80 dBm     | +/-1dB    |
|                   | 60Mbps   | -79 dBm     | +/-1dB    |

# Sensitivity

$$\frac{P_{RX}}{I_{RX} + N} \geq \theta_{(Rate, BER)}$$

Threshold  $\theta == \text{minSNR}$   
when  $I_{Rx} = 0$

sensitivity =  $N + \text{minSNR}$

| RX SPECIFICATIONS |          |             |           |
|-------------------|----------|-------------|-----------|
|                   | DataRate | Sensitivity | Tolerance |
| 802.11b           | 1Mbps    | -97 dBm     | +/-1dB    |
|                   | 2Mbps    | -96 dBm     | +/-1dB    |
|                   | 5.5Mbps  | -95 dBm     | +/-1dB    |
|                   | 11Mbps   | -92 dBm     | +/-1dB    |
| 802.11g OFDM      | 6Mbps    | -94 dBm     | +/-1dB    |
|                   | 9Mbps    | -93 dBm     | +/-1dB    |
|                   | 12Mbps   | -91 dBm     | +/-1dB    |
|                   | 18Mbps   | -90 dBm     | +/-1dB    |
|                   | 24Mbps   | -86 dBm     | +/-1dB    |
|                   | 36Mbps   | -83 dBm     | +/-1dB    |
|                   | 48Mbps   | -77 dBm     | +/-1dB    |
|                   | 54Mbps   | -74 dBm     | +/-1dB    |
| 802.11n HT        | 24Mbps   | -94 dBm     | +/-1dB    |
|                   | 48Mbps   | -91 dBm     | +/-1dB    |
|                   | 36Mbps   | -83 dBm     | +/-1dB    |
|                   | 54Mbps   | -80 dBm     | +/-1dB    |
|                   | 72Mbps   | -77 dBm     | +/-1dB    |



# Rates vs Sensitivity/SNR

- Different modulation schemes have different constellations
- Denser constellations carry more bits/point
  - higher rate
  - increased BER
  - needs larger SNR



# Path Loss

- Free Space propagation model  $PL = \frac{(4\pi d)^2}{\lambda^2}$
- Two Ray model  $PL = \frac{d^4}{h_{Tx}^2 h_{Rx}^2}$
- Log Distance model  $PL [\text{dB}] = PL(d_0) + 10n \log\left(\frac{d}{d_0}\right) + X_\sigma$




# Signal Propagation

- Reflection
- Diffraction
- Scattering
- MultiPath
  - Fading
  - Shadow



# Fresnel Zone





# At the Receiver

- Signal of Interest
  - Account path loss + delayed reflections
- Interference
  - Transmissions in the same or neighboring channels/frequencies
- Noise
  - Thermal + System noise

# Algebra

- When using Watt:
  - multiply, divide
- When using dB/dBm:
  - add, subtract



# decibel

- Relative measurement unit:  $10 \log_{10}\left(\frac{value}{1 \text{ unit}}\right)$
- Examples
- Rule of thumb: +10dB  $\Leftrightarrow$  x10

$$1mW = 10 \log_{10}\left(\frac{1mW}{1mW}\right) = 0dBm$$

$$10mW = 10 \log_{10}\left(\frac{10mW}{1mW}\right) = 10dBm$$

$$100mW = 10 \log_{10}\left(\frac{100mW}{1mW}\right) = 10 \log_{10}(10^2) = 20dBm$$

# decibel

- Rule of thumb: +3dB  $\Leftrightarrow$  x2

$$1mW = 10 \log_{10}\left(\frac{1mW}{1mW}\right) = 0dBm$$

$$2mW = 10 \log_{10}\left(\frac{2mW}{1mW}\right) = 10 \log_{10}(2) \simeq 3dBm$$



# decibel

- From dB to units:  $X \text{ dB}_{unit} = 10^{\frac{X}{10}} \text{ unit}$

$$15\text{dBm} = 10^{1.5}\text{mW} = 31.62\text{mW}$$

$$1\text{dBm} = 10^{0.1}\text{mW} = 1.26\text{mW}$$


$$17\text{dBm} = (20 - 3)\text{dBm} \simeq \frac{100}{2}\text{mW} = 50\text{mW}$$

# antennas

- The antenna provides three fundamental properties
  - Gain
  - Direction
  - Polarization
- Gain: (pos/neg) increase in power
- Direction: transmission shape/pattern
- Polarization: electric field oscillation axis orientation



# antennas



- Near/Far field
- Fraunhofer region

$$d_f = \frac{2D^2}{\lambda}$$
$$d_f \gg D$$
$$d_f \gg \lambda$$

# Received Power

- Power at the receiver (Rx)

$$P_{Rx} = P_{Tx} + G_{Tx} + G_{Rx} - PL$$

- Effective Isotropic Radiated Power

$$E.I.R.P. = P_{Tx} + G_{Tx}$$



# interference

- Everything on same channel
  - sum all powers
- On different channels
  - inter-channel power quotient

# Link Budget

- Predict the wireless link
- Estimate the Received Power =>
  - Rate (based on sensitivity/SNR)
- Use dB (additions & subtractions)



# Link Budget

- Example 1:
  - 802.11g , 54Mbps => -73dBm sens.
  - Tx Power 20dBm
  - EIRP 30dBm
  - distance covered?
- Example 2:
  - 802.11g
  - 2km distance
  - EIRP 20dBm
  - achievable rate?

# Link Budget

$$P_{Rx} = P_{Tx} + G_{Tx} + G_{Rx} - PL$$

$$P_{Rx} = E.I.R.P. + G_{Rx} - PL$$

$$PL = E.I.R.P. + G_{Rx} - P_{Rx}$$